



WOOD PORCH LANTERN

Supplies:

- (1) 1" x 8" x 8' board
- (1) 1" x 3" x 8' board
- (1) 2" x 2" x 8' board
- [Waterproof Wood Glue](#)
- [1.75" Brad Nails](#) or [1.75" exterior wood screws](#)
- Wood stain or paint if using untreated lumber (if these will be outside, use exterior-rated stain or paint)

Tools:

- Miter saw
- Drill & Small drill bit
- Brad Nailer
- Clamps (optional)
- Power Sander (or a sanding block)

Cut List: (20 pcs for option #1 or 12 pcs for option #2)

- Two 1" x 8" boards cut 7.25" (top and bottom)
- Four 2" x 2" boards cut 12" (risers)
- Four 2" x 2" boards cut 1" (feet)
- Eight 1" x 3" boards cut 4.25" (sides/ option #1 only)
- One 1" x 3" board cut 4" (decorative piece)
- One 1" x 3" board cut 5.5" (decorative piece)